

T: (07) 3040 0331 E: info@ledtubelighting.com.au W: www.ledtubelighting.com.au

Module LED Flood Light 10W



1 Features

- Unlike a traditional LED flood light which has a heat sink on the back of the lamp, our latest model has a special fin type heat sink built into the case. This makes the lamp lighter and provides for superior heat dissipation.
- The LED driver is installed away from the heat sink. This separation of the LED driver creates a lower heat working environment giving the lamp a longer life span.
- 3 IP67
- 4 Beautiful appearance using Philips LEDs with super luminous 120+LM/W.
- 5 A Mean Well LED driver. With 3 year guarantee.





T: (07) 3040 0331
E: info@ledtubelighting.com.au
W: www.ledtubelighting.com.au

2 Application of the lamp.

For outdoor lighting, such as architecture, industrial area, factory, gym, garden, sea port and so on.

3 Dimensions of the lamp.





4 Main technical parameters

Item No.	CCT	Ra	Lumens	Input Wattage	Lamp power			
WX-FG-M-10W	5000-5650K	≥70	960LM	AC 100-277V	12±1W			
LED: PHILIPS REBEL								
Storage Temperature : $-40 \sim 50^{\circ}$ C								




T: (07) 3040 0331


E: info@ledtubelighting.com.au

W: www.ledtubelighting.com.au

5 Light distribution parameters


10degree






30degree

60degree






T: (07) 3040 0331
E: info@ledtubelighting.com.au
W: www.ledtubelighting.com.au



60x135 degree



85x135degree



T: (07) 3040 0331
E: info@ledtubelighting.com.au
W: www.ledtubelighting.com.au

6 Package

Net weight/pc	Gross weight/pc	Carton	Inner box	Quantity/Carton
0.65KG	0.73	225*330*380mm	207*158*72mm	10pcs

7 Instructions for installation

- Cut off the power and make sure the wall can support the weight of the lamp before installing.
- Make sure the lamp is secure and correctly installed.
- Do not use the lamp in any area near flamable fumes or gases.
- Do not cover the lamp.
- Be careful and connect the ground wire.
- Altering the product or installing it incorrectly will void the warranty.

8 Instructions for installation.

